

WHAT SIZE HOLE SHALL I DIG FOR MY POST?

This guide is based on normal conditions.

You will also need to factor in and compensate for elements such as the height of the sign, the soil type (sandy or compact clay?) and exposure to the wind.

1M POST
350MM DEEP

2M POST
500MM DEEP

3M POST
600MM DEEP

AROUND THE POST

95MM SPACE
EITHER SIDE OF THE POST

190MM SPACE
FRONT & BACK OF THE POST

170MM SPACE
EITHER SIDE OF THE POST

335MM SPACE
FRONT & BACK OF THE POST

225MM SPACE
EITHER SIDE OF THE POST

450MM SPACE
FRONT & BACK OF THE POST

Dig the hole big enough to allow enough space for the Postcrete to pass down between the post and soil. There's nothing easier than using a post hole digger to minimise the digging.

