



Effective alternative

Used as an alternative to fitting a channel in boards. Much neater presentation and easy to fit. Dave.



BUTTON-FIX TYPE1



BUTTON FIX PANELS. INVISIBLE. LOCKABLE. THE FIXINGS REVOLUTION IS HERE.

The Button-fix concept is simple: durable polymer fixings are attached to the back of one panel and the mating buttons are attached to the other. Bring the panels together and slide until the Button-fix 'click'. Sold individually - one fix and one button per set.

For connecting panels where proven strength is paramount. Connects parallel panels where the emphasis is on strength. Highly versatile, it can be surface-mounted or semi-rebated into the panel, orientated for vertical or sideways assembly. Suitable for 5mm countersunk wood screws.

GREAT FOR: WALL & CEILING PANELS, ACOUSTIC PANELS, MIRROR PANELS, SHELF UNITS, SHOP DISPLAYS AND MORE.

The Button-fix marker tool accessory is also available and helps to quickly and accurately align the Button-fix installation, reducing the need for measuring and marking. Snap a marker into each Fix, then position the second panel and press firmly. The marker points will leave indents in the panel surface, which can be used as pilot guides for the Buttons

Signman suggests...

As an approximate guide, we suggest that Button-fix centres are no greater than 600mm apart and no closer than 35mm to the edge of the panel. Always remember to allow at least 15mm clearance for the removable panel to disengage.

Suitable adhesives:

The Fix is manufactured in ABS plastic. There are many structural adhesives suitable for bonding it to a wide range of panel materials e.g. a 2-part structural acrylic adhesive (Penloc, 3M Scotch-Weld) or a matched adhesive for solid surface (TIMco Multi-Fix).